

QUICK START GUIDE



1. Plug in the machine.
2. Follow the flashing lights. Press the button next to whatever light is flashing.
3. After you press LOAD four times, the start light will flash.
4. Once the start light flashes open the hopper lid (A), sprinkle tobacco into hopper, close lid.
5. Press START.
6. To add an empty cigarette tube, hold down lever (C), slide tube onto tube valve (B), release lever.
7. Press LOAD to inject tobacco into the tube.
(Repeat steps 6 & 7 nineteen more times to make 20 cigarettes)
(Open hopper lid at any time to add tobacco)

* Turning the compaction knob (D) clockwise makes cigarettes fuller.

* Press STOP at any time to halt operation and reset machine.

When you are done making cigarettes, clean all tobacco out of the hopper, then run the clean cycle by pressing: STOP, CLEAN, LOAD, LOAD, LOAD, LOAD.



TOBACCO MOISTURE IS IMPORTANT

To manage tobacco moisture, purchase a moisture meter at www.HardWorkingProducts.com and use tobacco that is at about 14% moisture content.

See more tips and register your product at www.hardworkingproducts.com.

IMPORTANT SAFEGUARDS

- Always remove tobacco from the hopper and run a clean cycle when you are done.
- Always unplug the machine when not in use.
- Do not leave the machine unattended while it is plugged in.
- This machine is designed for individual use.
- This machine should be operated by adults only.
- This machine requires no lubrication.